User manual

Indoor station for hands-free talking with special functions ISW3330

Operating and indication elements of the device



Loudspeaker for ring tones and voice

Lighting bar is illuminated **red** when the central is called **Green,** when the central calls back or during general announcements to a group

Press **call push button** to call the central

Microphone

Features of your indoor station ISW3330

The ISW3330 is an indoor station in a TCS door communication system. From your flat, you are able to

- call the central in your residential unit and speak to the central,
- receive general announcements from the central of your residential unit.

Calling the central and speaking

- Press the call button (3) (or the radio push button, if provided). The lighting bar (2) shines red, a short tone sounds. Or press the floor push button, a ring tone sounds, the lighting bar is OFF during this action. The call is sent to the central.
- The lighting bar (2) shines green, if the central starts communication with you.
- The central can communicate with you via the loudspeaker within the device and listen to you via the microphone.

Receive grouped announcements

- From the central, general announcements to a group of residents can be realised within your building.
- If an announcement is received, the lighting bar (2) shines red.
- The announcement cannot be switched OFF. The volume cannot be turned down.

Cleaning

!	Avoid water from entering the device! Do not use any abrasive detergents!

Clean the device with a dry or slightly wet cloth.
Remove stronger stains with a standard plastic cleaner.

The indoor station was installed and commissioned by:

Headquarters
TCS TürControlSysteme AG, Geschwister-Scholl-Str. 7, 39307 Genthin
Service: www.tcsag.de, hotline@tcsag.de